Easy call user manual

Contents

1. Safetv Precautions 3
2. Extra Safetv Precautions 3
3. Menu Tree.....5
4. Introduction to This Phone.....6
4.1 Keys.....7
5. Instructions.....7
5.1 Installation Instructions 7
5.2 Install the Battery and Battery Cover: 7
5.3 Charge/Recharge the Battery.....7
5.4 Use of Battery.....8
5.5 Turn On or Off.....8
5.6 Make a Call.....8
5.7 Adjust Volume 8
5.8 Answer a Call 8
5.9 Short-cut Numbers 8
5.10 Phone book.....8
5.11 Ring Tones.....9
5.12 SOS Function 9
5.13 Lock and Unlock keys.....9
5.14 Hands free 9
5.15 Alarm.....9
5.16 Call logs.....10
5.17 Earphone.....10
6. Maintenance 10
6.1 Specification Parameters 10
6.2 Battery Information 10
7. Troubleshooting.....10
8. Appendix .*Errore. Il segnalibro non è definito.*
8.1 Prompt Icon**Errore. Il segnalibro non è definito.**

1. Safety Precautions

Please read through the following briefings carefully, and act in accordance with these rules, so as to prevent causing any danger or violating any law.

Safe driving

1)Do not use the phone when driving. When you have to use the phone, use only with the hands-free kit.
2) Place the phone safely in the phone stand. Do not put it onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

Turn off during a flight

Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during a flight.

Turn off the phone when in the vicinity of areas with explosives or chemicals, flammable, dangerous or hazardous products

Be sure to strictly observe the related laws and statutes by turning off the phone when you are within, or in the vicinity of, an area where blasting takes place.

Please turn off your phone when you are within a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.

Hospital and Medical Facilities

Please obey the related rules or bylaws of the hospital when using your phone in a hospital. Be sure to turn off your phone when near any medical equipment. Your use of any wireless transmission equipment, inclusive of the phone, will interfere with any medical equipment or other electronic equipment.

Interference

Each and every phone's performance may be affected due to radio interference.

Professional service:

The phone must be installed or repaired by no other personnel than professionals. You are likely to suffer a huge risk when you install or repair this phone by yourself, which also goes against the warranty rules.

Fittings and battery

You shall use the fittings and battery acknowledged by the phone manufacturer only.

Proper use

Only use the phone as advised and described in this manual.

Avoid using the phone in areas that have cold or hot temperatures. Do not leave the phone exposed to direct sunlight or in areas very humid or dusty.

Extreme care and attention to be taken before using the phone near medical devices such as but not only as pacemakers, hearing aids, or other electro-medical units that may be subject to interference from a mobile phone.

The various components and parts can cause choking if swallowed.

To avoid demagnetization, avoid keeping the Phone and accessories in the vicinity of magnetic substances such as, but not only, magnetic discs or credit cards.

Do not throw or put the phone or parts or accessories near fire.

Keep the phone at least 2,2cm away from your body.

Emergency call

You may enter a telephone number (112, etc.) to ask for emergency help after making sure that the phone has been turned on and is in the service status. Press the Send Key to call out, and report your position and introduce what has happened briefly. Do not end the call without authorization.

Note: Like any other phone, this phone's specific features may not be supported by some network whose coverage or wireless signaling is troubled (some network does not support calling for emergency service by 112. Therefore, do not rely wholly on this phone in case of some especial emergency (such as medical first aid. etc.). Please consult your local network operator for verification.

2. Extra Safety Precautions

The unit and the accessories can contain small parts. Keep them out of the reach of small children.

OPERATING ENVIRONMENT

Remember to follow any particular rules that may apply wherever you happen to be, and always turn off the unit whenever its use is forbidden, or it can cause interference or danger. Only use the units in its normal user position. This unit complies with guidelines for radiation when it is used either in a normal position against your ear, or when it is at least 2.2 cm (7/8 inch) from your body. If the unit is carried close to your body in a case, belt holder or other holder, these should not contain any metal, and the product should be placed at the distance from yr body specified above. Make sure that the distance instructions above are followed until the transfer is complete.
Parts of the unit are magnetic, The unit can attract metal object. Do not keep credit cards or other magnetic media near the unit, as information stored on them can be erase.

MEDICAL UNITS

The use of equipment that transmits radio signals, e.g. mobile phones, can interfere with insufficiently protected medical apparatus. Consult a doctor or the manufacturer of the apparatus to determine if it has adequate protection against external radio signals, or if you have any question. If notices have been put up at health care facilities instructing you to turn off the unit while you are there, you should comply. Hospitals and other health care facilities sometimes use equipment that can be sensitive to external radio signals.

PACEMAKER

Pacemaker manufacturers recommend a distance at least 15 cm. (6 inches) between a mobile phone and a pacemaker to avoid the risk of interference with the pacemaker. These recommendations are in accordance with independent research and recommendations from Wireless Technology Research. People with pacemakers should:

- always keep the unit at a distance of at least 15 cm from the pacemaker.
- not carry the unit in a breast pocket
- hold the unit against the ear on the opposite side from the pacemaker to reduce the risk of interference. If you suspect that there is a risk of interference, turn off the unit and move it further away.

HEARING AIDS

Some digital wireless units can cause interference to some hearing aids. Contact yr operator in case of interference.

VEHICLES

Radio signals can affect electronic systems in motor vehicles (e.g. electronic fuel injection, ABS brakes, automatic cruise control, air bag systems) that have been incorrectly installed or are inadequately protected. Contact the manufacturer or its representative for more information about yr vehicle or any additional equipment.

Do not keep or transport flammable liquid gases or explosives together with the unit or its accessories. For vehicles equipped with air bags: remember that air bags fill with air with considerable force.

Do not place objects, including fixed or portable radio equipment in the area above the airbag or the area where it might expand. Serious injuries may be caused if the mobile phone equipment is incorrectly installed and the airbag fills with air.

It is forbidden to use the unit whilst flying. Turn off the unit before you board a plane. Using wireless telecom units inside a plane can involve risk for air safety and interfere with telecommunications. It can also be illegal.

AREAS WITH EXPLOSION RISK

Always turn off the unit when you are in an area where there is a risk of explosion and follow all signs and instructions. An explosion risk exists in the places that include areas where your normally requested to turn off your car engine. Within such an area, sparks can cause explosion or fire which can lead to personal injuries, even death.

Turn off the unit at filling stations i.e. near petrol pumps and garages.

Follow the restrictions that are in force on the use of radio equipment near places where fuel is stored and sold, chemical factories and places where blasting is in progress.

Areas with risk for explosion are often – but not always – clearly marked. This also applies to below decks on ships: the transport or storage of chemicals; vehicles that use liquid fuel (such as propane or butane); areas where the air contains chemicals or particles, such as grain, dust or metal powder.

EMERGENCY CALLS IMPORTANT!

Mobile phones such as this unit use radio signals, the mobile phone network, the terrestrial network and user-programmed functions. This means that connection in all circumstances cannot be guaranteed.

Therefore you should never rely solely on a mobile phone for very important calls such as medical emergencies.

SPECIFIC ABSOPTION RATE (SAR) CERTIFICATION INFORMATION

This model meets international guidelines for exposure to radio waves. Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines.

These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons regardless of age and health.The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The ICNIRP SAR limit for mobile devices used by the general public is 2.0 W/kg. As SAR is measured utilising the device’s highest transmitting power, the actual SAR of the device while operating is typically below the above indicated level. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level requested to reach the network. While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. The World Health Organization has stated that present scientific information does not indicate the need for any special precaution for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a “hands-free” device to keep the mobile phone away from the head and body.

WEEE REGULATIONS

The crossed-out wheeled bin means that within the European Union the product must be taken to separate collection at the products end-of-life. This applies to your device but also to any enhancements marked with this symbol. DO not dispose of these products as unsorted municipal waste.

3. Menu Tree

1	Contacts Menu	2	Contacts	3	Dial
					Add New Contact
					Search
					Edit
					Delete
					Ringtone
1	Call log	2	Received calls		
			Dialed calls		
			Call duration		
			Missed call		
1	Settings	2	Alarm clock		
			Clock Settings		
			SOS		
			M1 number		
			M2 number		

4. Introduction to This Phone

View

1	Up Button	5	Green LED Lights	9	Direct Dial number Button（M1,M2）
2	Down Button	6	Red LED Lights	10	Keypad
3	SOS Direct Dial Button	7	Screen	11	Loudspeaker/Microphone
4	Enter/Green Key	8	End/ Red Key	12	Charger /Earphone Socket

4.1 Keys

This phone has the following keys:

Key	Name	Annotations
	Send Key	Press to Dial or answer a call. Press to switch on / off handfree during conversation
	End Key	Press to end a call. Press for several seconds to turn the phone on or off. To cancel input of numbers to dial or to be saved.
	Up/ Down Key	Press to enter Main Menu. Long press to activate keypad lock Press to adjust the volume during conversation.
	Direct Dial Keys	Press key for rapid dialing phone numbers
	Signal Lights	1) Green light flashing: network signal is high 2) Red light flashing: battery is low. 3) Green light fixed: no network signal 4) Red light off: battery is sufficient. 5) Red light fixed: battery is charging.
	SOS	Press to dial SOS number.

5. Instructions

5.1 Installation Instructions

How To Install the SIM Card

THE PHONE MUST BE TURNED OFF AND DISCONNECTED FROM ANY DEVICE OR POWER SOURCE.

1) Turn the phone backside up and Gently press and push downwards the cover; preferably near the top of the phone, and gently remove.
2) Insert the SIM card, the seat is at the bottom on the left side, by very gently sliding the card into position .

Note: The cropped corner of the SIM card shall correspond to that of the outline of the seat and metal side downwards.

SIM CARD Codes / Password

ATTENTION: To activate or deactivate this function the SIM Card must be inserted in a standard GSM phone as this phone does not have this function.

—PIN1 code

PIN code（Personal identify number）prevents unauthorized use of your phone. The **PIN** code usually comes from your service provider along with the **SIM** card.

If you enter the wrong code three times continuously, the **PIN** code is locked. To unlock the **PIN** code, you need a personal unlocking key (**PUK**) from your service provider.

—PIN2 code

Some functions, call costs for example, require a second **PIN2** code. The **PIN2** code comes from your service provider along with some of the SIM cards, and these functions are only available when the SIM card supports them.

If you enter the wrong PIN2 code three times, the **PIN2** code is locked. To unlock the PIN2 code, you need a personal unblocking key (**PUK2**) from your service provider.

PIN CODE

When the phone is turned on the PIN1 appears.

1 Digit the correct Pin or PUK Code By pressing the number keys corresponding to the number to be entered.
2. Press the Send Key to confirm

SIM CARD Precautions.

1) Handle the SIM card with care, as scratches or bending damages the SIM card.
2) If the SIM card is inserted incorrectly or is invalid or damaged the screen will display ? after the phone is turned on.

Remove the SIM card, check if it has been inserted correctly and re-insert correctly.

3）If the screen still displays ?, contact the network operator.

5.2 Install the Battery and Battery Cover:

1) After installing the SIM Card to install the battery .
2) The metal contacts on the battery must be in correct position.
3) Very gently position the battery contacts to the phone contacts and very gently push into place.
4) Replace the battery cover, by very gently placing the cover in position and gently slide to lock onto the back.

5.3 Charge/Recharge the Battery

2) Gently push the charger plug into the socket; **ensure the plug is in the correct position ; shape of the plug matches the shape of the socket.**

3) Connect the other end of the charger to the power source.
4) When battery is full, switch of the power source, remove the charger from the power source and the telephone

Note:

1) If the remaining power in the battery is too low to turn on the phone, charge the battery until full before turning on again the phone.

2) Make sure that the standard voltage and power are correct for the battery charger.

3) During the charging/recharging period, you may turn on or off the phone, for better battery life it is best to have the phone turned off.

4) For safety it is best to never use the phone whilst connected to a power source and during charging.

4) Use the battery only for its intended purpose. Never use any charger or battery that is damaged or not original.

5.4 Use of Battery

Battery Power Reminder

1) If the battery is not in used for a long time, the same must be fully charged before use.
2) The battery can be charged and discharged many times, but it has a limited life time. When the conversation and standby times are noticeably shorter than usual, replace the battery.
3) The battery is rechargeable and optimal performance of a new battery is only obtained after several complete charge and discharge cycles.
4) When a new battery is used for the first time or if the battery has not been used for a prolonged period, it is necessary to connect disconnect and reconnect a second time the charger to commence the charging of the battery.

5.5 Turn On or Off

1) Press the key for a few seconds until the display lights up and the phone turns on.
2) Press the key for a few seconds until the turn of screen displays and the phone turns off.

To set the time on the display

On turning on the phone for the first time, of after removal of the battery for approximately 15 minutes or more, the time must be set.

1) Press up key ▲ to enter setting manual
2) Press the up/down key until the correct hours displays. Press the key to confirm and the cursor automatically moves onto the minutes.
3) Press the up/down key until the correct minute displays. Press the to confirm
4) The Phone automatically goes into standby.

5.6 Make a Call

After SIM card, battery have been installed correctly and time has been set and phone has been turned on.

1) Press the number keys corresponding to the phone number to be dialed and then press the send key. .
2) Press the End key to end the call.

5.7 Adjust Volume

During a call, you can press the Up and Down button on the left side to adjust the volume louder or quieter.

5.8 Answer a Call

When the phone rings to answer the call:

1) Press the Send key
2) To end the call, refuse and not answer a call, press the End key

5.9 Short-cut Numbers

To insert and save M1 or M2 or SOS number

1) In the standby screen, press the Up key ▲ to enter the setting menu screen
2) Press the Up or Down button to scroll options
3) Press the to select option
4) Insert number to be memorized to the button.
5) Press the to confirm.

Note: Whilst inputting the numbers: Press the end key to delete the number behind the cursor.

5.10 Phone book

To view phone book records. In standby screen, press down ▼ key or select from main menu

Dial from phonebook

1) Enter phonebook records
2) Press the up ▲ or down ▼ key to select phonebook records
3) Press the to select options
4) select dial option and Press the to call the number

New Entry a Phone Record

1) Enter phonebook records
2) Press the to select options

4) Select Add new and enter the number
5) Press the to confirm and select the ringtone
5) Press the to confirm.

Edit Phonebook Record
1) Enter phonebook records
2) Press the up ▲ or down ▼ key to select phonebook records
3) Press the to select options
4) select eidt option and Press the to start edit the number
5) Press the to confirm the changes and ringtone.

Search a phone number
1) Enter phonebook records
2) Press the  to select options
4) Select Search option and enter number digits to search
5) Press the to confirm and start searching

Delete a phone number
1) Enter phonebook records
2) Press the up ▲ or down ▼ key to select phonebook records
3) Press the to select options
4) select delete option and Press the to start delete
5) Press the  again to confirm the delete.

5.11 Ring Tones
1) Enter phonebook records
2) Press the  to select options
4) Select Ringtone option and select ringtone to this phonebook record
5) Press the to confirm

5.12 SOS Function
This function allows the phone to automatically dial the short-cut number and send an SMS with written "HELP" and not automatically dial emergency services.
Note: IF the SIM card does not have credit or can not call out for any reason then to make an SOS call to emergency services the Button must be pressed twice.

1) Press for at lest 2- 3 seconds the SOS button to make the call.
2) Press the end key to cancel the call.

5.13 Lock and Unlock keys.

1) Press at least 2 ~ 3 seconds the Up Key ▲
On the LCD display the 🔒 *symbol appears.*

Unlock the Keys
1) Press at least 2 3 seconds the Up Key ▲

5.14 Hands free

To activate the hands free (loudspeaker) press the
To deactivate the hands free (loudspeaker) Press the

5.15 Alarm
To insert and save
1) In the standby screen, press the Up key ▲ to enter the setting menu screen
2) Press the ▼ to scroll options
3) Press the  to select alarm option
4) Digit the time for setting the alarm.

5) Press the to confirm.

5.16 Call logs

Note: Call duration, calls received and dialled calls can be viewed only. Missed calls can be dialled.

1) In the standby screen, press the Send/Green key to enter the call log menu.
2) Press the ▼ to scroll options
3) Press the to select option
4) Press the to select missed call to be dialed.
5) Press the to confirm and dial.

5.17 Earphone

Insert the earphone into the socket on the phone and the same is automatically activated.

To deactivate the earphone it is just to be unplugged-

6. Maintenance

※ Put the phone and all of its fittings in a place out of children's reach.

※ Keep the SIM card in good conditions. Do not bend or scraper it; be sure to avoid it from interference by static electricity. Use a piece of cloth that is static electricity proofing, and contains no chemical detergent, to clean the SIM card.

※ The phone shall be kept from moisture and shaking. Do not put it in any place directly exposed to sunshine. Any liquid flowing into the phone will cause corrosion of the metal made electric circuit; and heat will shorten the service lives of the electronic component parts and damage the battery.

※ If the phone is not in use for a long time (more than one month), please take out the battery.

※ Phone ID: when you have lost your phone or SIM card, the following information is rather important, and shall be recorded: SIM card serial number (marked on the card); phone serial number (15-digit), and client number given by the network operator.

※ If you have lost your phone or SIM card, please contact your network operator immediately, to prevent any other person from using your phone illegally.

※ If the phone is not in use for a long time after being turned off, please separate the phone from its battery, so as to avoid the battery from suffering an electric leakage, and thus damaging the phone. If the battery is not in use for a long time (or has discharged its power), and cannot be charged normally by use of a traveler's charger, please use the charging stand to resume its charging performance.

6.1 Specification Parameters

Network Type: GSM900MHz/DCS1800MHz
Dimensions: 100 x 53 x 14mm
Working Voltage: 3.7V-4.2V
Battery : 700mAh
Standby Time duration : 64 hours approximately
Maximum Call Time : 4.5 hours approximately

6.2 Battery Information

※ Do not throw the battery into fire.
※ Do not dismantle or retrofit the battery.
※ Do not put the battery in any place in can be subject to mechanical solicitations in particular do not perforate the battery by use of any object.
※ The battery shall be kept in a cool and dry place, and away from high or low temperatures or exposure to direct sunshine.
※ Do not use the lithium battery in a cold environment as this reduces the battery's power and charge
※ Do not clean or bring the battery into contact with any liquid (example: water, solvent, oil).
※ Stop immediately use of the battery in case of odour of any kind or the phone and/or battery appear to be warmer than normal or a cool temperature.
※ Stop immediately the use of the battery if it has any sign of alteration ; for example: cracked or cracks, shape is deformed or swollen, leakage or oxidation..
※ In case of contact of leakage with any surface, material or skin: rinse or wipe clean with soap and clean water immediately. In case of contact with eyes: rinse immediately with clean water and contact qualified medical assistance immediately.
※ Use only original battery and charger, to avoid any damage or risks.
※ Always turn off the phone before and during handling the battery.
※ **Always dispose of the battery as per local regulations.**

7. Problèmes et solutions

Lors de la mise sous tension du Téléphone, l'écran peut afficher le message suivant.

- ?

  Vérifier que la carte SIM est correctement insérée.
- PIN1

1） Si vous utilisez le Téléphone pour la première fois, vous devez saisir le numéro PIN fourni avec la carte SIM.

2） PIN verrouillé. Chaque fois que vous allumez Votre Téléphone, vous devez saisir le numéro PIN.

Lors de l'usage de Votre Téléphone, l'écran peut afficher les icônes suivantes :

- 

Votre Téléphone est en train de lire les informations de contact disponibles sur la carte SIM avant de s'allumer, il lui faut un peu de temps pour les lire. Attendre SVP.

Le pave numérique est verrouillé, appuyez sur ▲ pendant 3 secondes pour le déverrouiller.

-

Si l'écran affiche cette icône, cela signifie que le service de la carte SIM est limité ; il affiche de même le message "Secours appels uniquement". Le numéro de secours est le 112.

-

Si l'écran affiche cette icône, cela signifie que la carte SIM est pleine et vous ne pouvez rien y ajouter.

Vous avez saisi le numéro, mais vous ne pouvez pas effectuer l'appel

- Vérifier d'avoir appuyé sur
- Vérifier d'avoir sélectionné le réseau correct de téléphonie mobile

Personne ne peut vous contacter

Vérifier que votre Téléphone est allumé (appuyer pendant 2 secondes sur)

- Vérifier d'avoir sélectionné le réseau correct de téléphonie mobile

L'abonné qui vous appelle ne vous entend pas.

- Parler fort et en proximité du microphone qui est situé en bas du combiné.

Votre Téléphone émet un beep et l'icône du niveau de la batterie affiche qu'elle est vide et le témoin situé à droite est en train de clignoter

Cela signifie que la batterie est vide et doit être rechargée.

La qualité de la connexion est mauvaise.

- Vérifier la puissance de l'indicateur du signal à l'écran le nombre de carrés du dit indicateur indique la puissance du signal ; s'il affiche , cela signifie que le signal est puissant. S'il affiche , cela signifie que le signal est faible. S'il affiche , cela signifie que le signal est absent.

- Si vous êtes dans un bâtiment, déplacez-vous pour trouver le meilleur emplacement qui présente un bon signal ou vers la

fenêtre.

Vous avez sélectionné un numéro du répertoire, mais Votre Téléphone n'effectue pas l'appel :

- Consulter le répertoire et vérifier d’avoir sauvegardé correctement le numéro.
- Si nécessaire, sauvegarder de nouveau le numéro.

Lorsque le chargement de la batterie présente des anomalies ou que le Téléphone s’éteint continuellement :

- A l'aide d'un chiffon sec, propre et moelleux, nettoyer le Téléphone et les points de contact de la batterie.

8. Appendix

8.1 Prompt Icon

Dialing or Incoming call	Charging	 Loading contracts
End call	Please wait	Sim card full
 Call duration	Select ringtone	Insert Sim card
No level	Ring	Sim card empty
Search for	Delete ?	Done or ok
 Input number	List empty	Not done or cancle
Locked Keypad	 Unlocking keypad	Locking keypad
Handfree	Missed call	Emergency call
Entry PIN 1	Entry PIN 1	Battery low